

SPECIFICATIONS

Suction Guide

Suction Guide shall be installed at the inlet of each pump. Suction Guide shall have MS/CI body, outlet guide vanes, removable SS strainer and fine mesh brass/SS start-up strainer.

The strainer shall be corrugated type with minimum of 5 times free area of the pipe cross-section.

The Contractor shall inspect the strainer prior to start-up of the pump and shall remove the fine mesh brass strainer after short running period. Space shall be provided for removal of strainer and for connection of blow down valve.